





FOR ATTENTION




CAUTION
Scissor sections of frame are a pinching hazard

- Take Shelter Down in Heavy Wind
- Allow fabric to dry before putting away
- Store in cover bag when tent is not in use




1 Remove frame from bag. Extend the frame partially by pulling outwards.

2




2 Apply canopy loosely over the frame.


3



3 Continue to extend frame by pulling outwards until corner snap button "clicks" into position




4




4 Pull canopy down tightly over the corners of the frame

5




5 Secure all interior velcro fastenings

6



6 While standing on triangular foot, extend the tent legs by pulling up until snap button "clicks into place."


7






SECURING TENT

option A Secure using Guy Ropes and Pegs through Canopy Loops




option B Secure using Pegs through the Holes in Tent Feet




Note: Hammer/Mallet required for pegs


COLLAPSING TENT




Depress Snap Buttons on all legs and retract lower section of the leg inside the upper section.



Release Frame Corner Auto Slider by pressing Snap Button




Slowly collapse frame by pushing in on itself. Remove Canopy as it starts to slacken



Collapse frame entirely




ASSEMBLY OF WALL(S) - OPTIONAL



NOTE: When adding the wall(s) to the tent, the legs on the frame (A) must be at their maximum extension height.

1. Attach the wall(s) to the valance on the tent using the hook-and-loop straps and or velcro attachments.
2. Secure the sides of the wall(s) by wrapping the hook-and-loop straps around the tent legs.
3. If the tent wall features zippers, walls can be connected by closing the zipper from bottom to the top.

ASSEMBLY OF HALF WALL(S) - OPTIONAL



NOTE: If attaching two or more half walls, you **MUST** stagger the height of **ADJOINING** half walls.

1. Slide one support pole (D) with the push button into the middle pole (C). The push button should snap through the near side hole. Assemble the second support pole (D) the same way.
2. Slide the half wall support bar into the pole sleeve of the wall fabric. The support bar should go through the entire pole sleeve, with both ends of the pole sticking out from the pole sleeve. Ensure pre-drilled holes are visible.
3. Attach the half wall clamps. Unscrew the knobs completely from the clamps (E) and use 2 separated pieces of the clamp to sandwich one leg.
4. Place the one end of the support bar through the opening of the clamp, and line up the pre-drilled holes. Insert the thumb screw into the open holes and hand tighten the knob. Assemble the second clamp and support pole the same way on the opposite end.
5. Secure the hook-and-loop straps of the half walls around the tent legs.